

# QUICK SETUP®: 12x8 SYSTEM

## Components



**Part A** Adjustable Crossbar (72-144" x 1.5") — x1



**Part B** Vertical Pole (96" x 2") — x2



**Part C** Base Plate (14" x 16") — x2



## StepRepeat® Installation Instructions

- Step 1** Screw Bottom Vertical Pole **B** into Base Plate **C**. Be sure that the Velcro is facing the front (performed 2x)
- Step 2** Place Vertical Poles **B** 12 feet apart.
- Step 3** Expand Upper Crossbar **A** until it locks in the 2nd position.
- Step 4** Unroll the StepRepeat® Banner on the ground face up with the pole pocket directly in front of the stand.
- Step 5** Slide Upper Crossbar **A** through StepRepeat® Banner Pole Pocket
- Step 6** Now it's time to hang the StepRepeat® on the frame. It is best to have 2 people for this job and a step stool. Attach Upper Crossbar **A** (that has been inserted into the pole pocket) to Vertical Uprights by inserting Crossbar connection hooks into the slots provided in Top Vertical Pole **B**
- Step 7** Be sure to pull the banner tight using the Velcro that is on the back of the banner the front of Vertical Poles **B**

**IMPORTANT:** A minimum of 25lbs of additional weight per side is recommended for Indoor use and 75lbs for Outdoor. To avoid injury or damage to your StepRepeat®, do not assemble in windy conditions.

Please check package contents carefully to familiarize yourself with the components required for installation.

Call us at [800.538.6544](tel:800.538.6544) for any issues you might have regarding output, equipment and installation.

