

QUICK SETUP®: 20x8 SYSTEM

Components



Part A Crossbar (96-144" x 1.5") – x2



Part B Vertical Pole (96" x 2") – x3
2 Poles with Velcro and 1 without. The poles with Velcro go on each end.



Part C Base Plate (14" x 16") – x3



StepRepeat® Installation Instructions

- Step 1** Screw Bottom Vertical Pole **B** into Base Plate **C**. Be sure that the Velcro is facing the front (*performed 3x*)
- Step 2** Place Vertical Poles **B** 10 feet apart.
- Step 3** Unroll the StepRepeat® Banner on the ground face up with the pole pocket directly in front of the stand.
- Step 4** Extend and slide each Upper Crossbar **A** through StepRepeat® Banner Pole Pockets
- Step 5** Now it's time to hang the StepRepeat® on the frame. It is best to have 2 people for this job and a step stool. Attach Upper Crossbar **A** (that has been inserted into the pole pocket) to Vertical Uprights by inserting Crossbar connection hooks into the slots provided in Top Vertical Pole **B**
- Step 6** Be sure to pull the banner tight using the Velcro that is on the back of the banner the front of Vertical Poles **B**

IMPORTANT: A minimum of 25lbs of additional weight per base plate is recommended for Indoor use and 75lbs for Outdoor. To avoid injury or damage to your StepRepeat®, do not assemble in windy conditions.

Please check package contents carefully to familiarize yourself with the components required for installation.

Call us at **800.538.6544** for any issues you might have regarding output, equipment and installation.