

# 5-MINUTE SETUP®: 5x8 DISPLAY

## Components

**Part A** Crossbar (60" x 1.5") — x2





**Part B** Bottom Vertical Pole (48" x 2") — x2



**Part C** Top Vertical Pole (48" x 2") — x2



**Part D** Base Plate (14" x 6") — x2



## StepRepeat® Installation Instructions

- Step 1** Screw Bottom Vertical Pole **B** into Base Plate **D** (performed 2x)
- Step 2** Insert Top Vertical Pole **C** into Bottom Vertical Pole **B** (performed 2x)
- Step 3** Place Vertical Uprights 5 feet apart
- Step 4** Attached Lower Crossbar **A** to the Vertical Uprights by inserting in into the lower slots
- Step 5** Slide Upper Crossbar **A** through StepRepeat® Banner Pole Pocket
- Step 6** Attach Upper Crossbar **A** to Vertical Uprights by inserting Crossbar connection hooks into the slots provided in Top Vertical Pole **C**
- Step 7** Unroll StepRepeat® Banner, attaching upper and lower corners to Vertical Uprights with Velcro Strips (provided) to remove any waves or wrinkles.

**IMPORTANT:** A minimum of 25lbs of additional weight per side is recommended for Indoor use and 75lbs for Outdoor. To avoid injury or damage to your StepRepeat®, do not assemble in windy conditions.

Please check package contents carefully to familiarize yourself with the components required for installation.

Call us at [800.538.6544](tel:800.538.6544) for any issues you might have regarding output, equipment and installation.